

## Simple Rear Wheel Alignment

By: Kiwi (brp650forum.com)

The easiest way to check and adjust the rear wheel alignment on the Ninja 650R (ER-6F) and ER-6N is to place the bike on a rear maintenance stand, mark the centre of the swing-arm pivot bolt and axle bolt (both sides) using either a marker pen (Sharpie) or a centre punch if you want something more permanent.

Using a tape measure check the distance between the centre markings on the swing-arm pivot bolt and the axle bolt both sides, they should be equal.



Thanks to BRP & F16Viper68 (brp650forum.com) for the content.